



# ART THATCH™

Palapa Structures  
5390 E Los Angeles Ave. Unit B  
Somis, CA 93066  
Phone: (805) 386-0306  
[www.palapastructures.com](http://www.palapastructures.com)  
[info@palapastructures.com](mailto:info@palapastructures.com)

## Easy Installation!

- ▶ Ideal for installation on all solid or open roof designs and any Art Thatch™ Umbrella Kit (sold separately).
- ▶ Realistic, artificial palm thatch panels conform and adjust to any custom roof design.
- ▶ Install our Baja Palm™ Top Cone (sold separately) on any custom roof peak.



## Baja Palm™ 10-Layer Umbrella Thatch Panel

### Specifications


- Length: 31"
- Height: 19"
- Width: 1"
- Coverage: 2.15 Sq. Ft.
- Center Installation: 10"
- 20 Year Limited Warranty
- Offered as both Class A fire rated and non-fire rated



# Baja Palm™ 10-Layer Umbrella Thatch Panel Installation Tips


## Non Waterproof Installation

- Panels are visible from underneath.
- Best to use 30 degree roof pitch.
- Clip panels to 3/8" bar stock or custom wood supports.
- Panels should have an overhang at the bottom or eave of 12-16".
- Cut with razor knife or saw (hacksaw, jigsaw, sawzall) with an 18 TPI blade.
- When installed on an ArtThatch™ Umbrella frame, refer to the instructions included with the kit.




## Waterproof Installation

- On a solid roof, panels are not visible from underneath.
- Best to use 30 degree roof pitch.
- Use waterproof underlayment under panels.
- Remove clips and attach with galvanized or stainless screws, roofing nails or pneumatic staples.
- Panels should have an overhang at the bottom or eave of 12-16".
- Cut with razor knife or saw (hacksaw, jigsaw, sawzall) with an 18 TPI blade.



## Hip Installation

- Thatch panels will bend around a hip.
- Cut with razor knife or saw (hacksaw, jigsaw, sawzall) with an 18 TPI blade.
- Use panels cut in half to cover the hip line. Contact the manufacturer if assistance is required.
- Install our Baja Palm™ Top Cone (sold separately) on any custom roof peak.



## Valley Installation

- Cut thatch panels at proper angle to fit tightly into the valley.
- Cut with razor knife or saw (hacksaw, jigsaw, sawzall) with an 18 TPI blade.

